


RAVEL LCD QUARTZ WATCH INSTRUCTIONS



S1 RESET
Reset Button

S2 START
Start Button

S3 MODE
Mode Button

S4 LIGHT
Light Button

SU - Sunday
MO - Monday
TU - Tuesday
WE - Wednesday
TH - Thursday
FR - Friday
SA - Saturday
AM - Morning
PM - Afternoon

HOW TO SET THE TIME, DATE, WEEK

1. Press **S3** three times so seconds are flashing.
2. Press **S1** so minutes are flashing and use **S2** to calibrate minutes.
3. Press **S1** so the hour is flashing and use **S2** to calibrate the hour.
4. Press **S1** so the day is flashing to calibrate the day.
5. Press **S1** so the month is flashing to calibrate the month.
6. Press **S1** so the week is flashing to calibrate the week.
7. Press **S3** to return to normal mode.

HOW CHANGE THE 12/24HR FORMAT

1. Press **S3** three times, press **S1** twice and then press **S2** to toggle between 12 and 24-hour clock.

HOW TO SET THE ALARM

1. Press **S3** twice, (the hour starts to flash).
2. Press **S2** to set the hour alarm.
3. Press **S1** once (the minute will start to flash).
4. Press **S2** to set the minute alarm.
5. Press **S3** to return to normal mode.

HOW TO SET UP THE CHIME

1. Press **S1** and **S3** simultaneously (week display is shown).
2. Release to return to normal mode.
3. Re-press **S1** and **S3** to stop the chime (week display missing).

HOW TO OPEN AND CLOSE THE CHIME AND ALARM

1. Press both **S1** and **S2** chime and alarm opened (displayed on the watch).
2. Press both **S1** and **S2** again chime and alarm closed (no display on the watch).

HOW TO USE THE LIGHT

1. Press **S4** at any time.

HOW TO USE THE STOPWATCH (1/100 SECOND)

1. Press **S3** once (All display is zero).

The stopwatch has three timing modes when the timing for any mode is over press **S3** to return to normal mode.

A) ELAPSED TIME MEASUREMENT

S2 START S2 STOP S2 RESTART S2 STOP S1 RESET

B) SPLIT TIME MEASUREMENT

S2 START S1 SPLIT S1 SPLIT RELEASE S2 STOP S1 RESET

C) SPLIT TIME MEASUREMENT

S2 START S1 SPLIT S2 STOP S1 SPLIT RELEASE S1 RESET

The first player
has completed

The second
player has
completed
Record the
elapsed time
for first player

Record the
elapsed time for
second player

WATER RESISTANCE (W/R)

GRADE	No W/R STATED	3ATM / 30M W/R	5ATM / 50M W/R	10ATM / 100M W/R
ACCIDENTAL SPLASHES / RAIN	✓	✓	✓	✓
SHOWERING / WASHING UP	✗	✓	✓	✓
SWIMMING / BATHING	✗	✗	✓	✓
SNORKELLING / DIVING / WATER SPORTS	✗	✗	✗	✓

**CUSTOMER SERVICE / KLANTENSERVICE
KUNDENDIENST SERVICE CLIENTS
ASSISTENZA CLIENTI / SERVICIO AL CLIENTE
OBSŁUGA KLIENTA / MÜŞTERİ SERVİSİ**

UK: TIMESOURCE LTD:

Units 1 & 2 Chater Court, Halifax Drive,
Northfields Industrial Estate. Market Deeping.
Lincs. PE6 8AH. UK.

EU: TIMESOURCE LTD - DUTCH BRANCH

Keizersgracht 241
1016 EA Amsterdam
The Netherlands.

CE Representative:

Timeworx LTD
45 Andrea Demetriou Str
Nicosia, Cyprus. 2024
thasosm@timeworx.eu
+357 22441328

