


RAVEL DUAL TIME QUARTZ WATCH INSTRUCTIONS



S1 RESET
Reset Button

S2 START
Start Button

S3 MODE
Mode Button

S4 LIGHT
Light Button

SU - Sunday
MO - Monday
TU - Tuesday
WE - Wednesday
TH - Thursday
FR - Friday
SA - Saturday
AM - Morning
PM - Afternoon

HOW TO SET THE TIME, DATE, WEEK

1. Press **S3** until time screen shows and seconds are flashing.
2. Press **S1** so minutes are flashing and use **S2** to calibrate the hour.
3. Press **S1** so the hour is flashing and use **S2** to calibrate minutes.
4. Press **S1** so the month is flashing to calibrate the day.
5. Press **S1** so the day is flashing to calibrate the month.
6. Press **S1** so the week is flashing to calibrate the day of the week.
7. Press **S3** to return to normal mode.

HOW CHANGE THE 12/24HR FORMAT

1. Press **S3** three times, press **S1** once and then press **S2** to toggle through the numbers to set either 12 or 24-hour clock. A = AM, P = PM, H = 24 hour.

HOW TO SET THE ALARM

1. Press **S3** twice to get to the alarm screen from the time screen.
2. Press **S1** to start the hour flashing.
3. Press **S2** to set the hour alarm.
4. Press **S1** once (the minute will start to flash).
5. Press **S2** to set the minute alarm.
6. Press **S3** to return to normal mode.

HOW TO OPEN AND CLOSE THE CHIME AND ALARM

1. Press **S3** until the alarm screen is shown.
2. Press **S2** to open the chime (bell icon shown).
3. Press **S2** again to open signal (SIG display shown) and close alarm.
4. Press **S2** again to open signal and alarm.
5. Press **S2** again to close signal and alarm.

HOW TO USE THE LIGHT

1. Press **S4** at any time.

HOW TO USE THE STOPWATCH (1/100 SECOND)

1. Press **S3** once (All display is zero).

The stopwatch has three timing modes when the timing for any mode is over press **S3** to return to normal mode.

A) ELAPSED TIME MEASUREMENT

S2 START S2 STOP S2 RESTART S2 STOP S1 RESET

B) SPLIT TIME MEASUREMENT

S2 START S1 SPLIT S1 SPLIT RELEASE S2 STOP S1 RESET

C) SPLIT TIME MEASUREMENT

S2 START S1 SPLIT S2 STOP S1 SPLIT RELEASE S1 RESET

The first player
has completed

The second
player has
completed
Record the
elapsed time
for first player

Record the
elapsed time for
second player

WATER RESISTANCE (W/R)

GRADE	No W/R STATED	3ATM / 30M W/R	5ATM / 50M W/R	10ATM / 100M W/R
ACCIDENTAL SPLASHES / RAIN	✓	✓	✓	✓
SHOWERING / WASHING UP	✗	✓	✓	✓
SWIMMING / BATHING	✗	✗	✓	✓
SNORKELLING / DIVING / WATER SPORTS	✗	✗	✗	✓

**CUSTOMER SERVICE / KLANTENSERVICE
KUNDENDIENST SERVICE CLIENTS
ASSISTENZA CLIENTI / SERVIZIO AL CLIENTE
OBŚLUGA KLIENTA / MÜŞTERİ SERVİSİ**

UK: TIMESOURCE LTD:

Units 1 & 2 Chater Court, Halifax Drive,
Northfields Industrial Estate. Market Deeping.
Lincs. PE6 8AH. UK.

EU: TIMESOURCE LTD - DUTCH BRANCH

Keizersgracht 241
1016 EA Amsterdam
The Netherlands.

CE Representative:

Timeworx LTD
45 Andrea Demetriou Str
Nicosia, Cyprus. 2024
thasosm@timeworx.eu
+357 22441328



Co.Reg. 5038155

**UK
CA**

CAUTION



Not suitable for
children under 3
years old due to
small parts.



CE